



INFORMATION ON BATTERY MAINTENANCE

Dear etropolis customer,

to ensure that you experience long lasting joy with your etropolis scooter please follow these instructions:

If in any case the scooter is not used for more than 4 weeks, please make sure to recharge the battery at least once a month.

The battery should never be completely discharged.

If your scooter loses power you also should recharge the battery.

Only by obeying these instructions you can make sure to have a long lasting battery life.

Have a safe journey and enjoy your etropolis scooter.

Your etropolis Team

